



TILLMAN®

Sizing Chart

PICK THE RIGHT SIZE FOR YOU

Jacket Sizes

1. Sleeves

Measure from the nape of neck to the shoulder point and then to the wrist.

2. Chest

Measure across breast and around back.

3. Jacket Length

Measure from the back of collar seam to the desired hem length.



Jacket Length

Jacket lengths from 26" to 48".



26"

30"

36"

48"

Size Chart

Small	36" - 38"	2X Large	52" - 54"
Medium	40" - 42"	3X Large	56" - 58"
Large	44" - 46"	4X Large	60" - 62"
X Large	48" - 50"	5X Large	64" - 66"

Bib Length

Tillman offers several different bib lengths from 14" to 30".



14"

20"

24"

30"

Bib Apron Length

Lengths from 30" to 48".



30"

36"

42"

48"

Waist Apron Length

Lengths from 14" to 30".



18"

24"

36"

40"